



IMG-111

Industrial M2M Gateway

User's Manual

Version 1.0
January, 2013

www.oring-networking.com



COPYRIGHT NOTICE

Copyright © 2011 ORing Industrial Networking Corp.

All rights reserved.

No part of this publication may be reproduced in any form without the prior written consent of ORing Industrial Networking Corp.

TRADEMARKS



is a registered trademark of ORing Industrial Networking Corp.

All other trademarks belong to their respective owners.

REGULATORY COMPLIANCE STATEMENT

Product(s) associated with this publication complies/comply with all applicable regulations.

Please refer to the Technical Specifications section for more details.

WARRANTY

ORing warrants that all ORing products are free from defects in material and workmanship for a specified warranty period from the invoice date (5 years for most products). ORing will repair or replace products found by ORing to be defective within this warranty period, with shipment expenses apportioned by ORing and the distributor. This warranty does not cover product modifications or repairs done by persons other than ORing-approved personnel, and this warranty does not apply to ORing products that are misused, abused, improperly installed, or damaged by accidents.

Please refer to the Technical Specifications section for the actual warranty period(s) of the product(s) associated with this publication.

DISCLAIMER

Information in this publication is intended to be accurate. ORing shall not be responsible for its use or infringements on third-parties as a result of its use. There may occasionally be unintentional errors on this publication. ORing reserves the right to revise the contents of this publication without notice.

CONTACT INFORMATION

ORing Industrial Networking Corp.

3F., No.542-2, Zhongzheng Rd., Xindian Dist., New Taipei City 23148, Taiwan (R.O.C.)

Tel: +886-2-2218-1066 // Fax: +886-2-2218-1014

Website: www.oring-networking.com

Technical Support

E-mail: support@oring-networking.com

Sales Contact

E-mail: sales@oring-networking.com (Headquarters)

sales@oring-networking.com.cn (China)



Tables of Contents

| | |
|---|----------|
| Getting to Know your M2M Gateway | 1 |
| 1.1 Overview | 1 |
| 1.2 Software Features | 1 |
| 1.3 Hardware Features | 2 |
| Hardware Installation | 3 |
| 2.1 DIN-Rail Installation | 3 |
| 2.2 Wall-Mounted Installation | 4 |
| 2.3 SIM Card Installation | 4 |
| Hardware Overview | 5 |
| 3.1 Front Panel | 5 |
| 3.2 Front Panel LEIMG | 6 |
| Cables and Antenna | 6 |
| 4.1 Ethernet Cables | 6 |
| 4.2 10BASE-T/100BASE-T(X) Pin Assignments | 6 |
| 4.3 Wireless Antenna | 8 |
| Management Interface | 9 |
| 5.1 First-time Installation | 9 |
| 5.2 M2M Gateway Configuration | 10 |
| 5.3 Main Interface | 10 |
| 5.3.1 Basic Setting | 11 |
| WAN | 11 |
| LAN | 12 |
| DHCP | 13 |
| 5.3.2 Serial Setting | 14 |
| Remote management | 14 |
| Serial Configuration | 15 |
| Port Profile | 16 |
| Service Mode – Virtual COM Mode | 17 |
| Service Mode – TCP Server Mode | 17 |
| Service Mode – TCP Client Mode | 18 |
| Service Mode – UDP Client Mode | 19 |
| 5.3.3 Advanced Settings | 20 |
| NAT Setting | 20 |
| Security Setting | 23 |
| VPN Setting | 25 |
| Routing Protocol (Routing Setting) | 32 |
| Miscellaneous DDNS | 34 |



| | | |
|---------------------------------------|----------------------------------|-----------|
| 5.3.4 | System Tools..... | 35 |
| | Date & Time..... | 35 |
| | System Event..... | 36 |
| | Login Setting..... | 36 |
| | M2M Gateway Restart..... | 37 |
| | Firmware Upgrade..... | 38 |
| | Save/Restore Configurations..... | 38 |
| | Remote management..... | 39 |
| | Miscellaneous (Ping)..... | 39 |
| 5.3.5 | System Status..... | 40 |
| | System Info..... | 40 |
| | System Log..... | 40 |
| | Traffic Statistics..... | 41 |
| 5.4 | DS-tool..... | 41 |
| Technical Specifications | | 51 |

Getting to Know your M2M Gateway

1.1 Overview

The ORing IMG-111 M2M Gateway is designed to operate in industrial environment. The M2M Gateway provides a fast and effective ways of communicating to the internet over wired LAN. And also include a RS-232 interface which allow user to get the RS-232 data through 3G.connection.

With built-in HSUPA WAN connection the ORing IMG-111 M2M Gateway can be mounted in harsh environment easily to provide internet access anytime and anywhere.

The ORing IMG-111 M2M Gateway's VPN capability creates encrypted "Virtual Tunnels" through the internet, allowing remote or traveling users for secured connection with the network in your office.



1.2 Software Features

- Secured Management by HTTPS
- Intuitive Web-based management user interface for simply and easily operation.
- Functions of firewall provides many security features such as blocking attacks from hacker, especially IP Spoofing, Ping flood, Ping of Death, DoS, DRDoS, Stealth Scan, etc.
- Advanced firewall configuration to extend the capability and security, such as Virtual Server, Port Trigger, DMZ host, UPnP auto Forwarding, IP Filter and MAC filter.
- Event Warning by Syslog and Relay
- Serial Data Encryption with SSL for Security data transfer.
- Redundant multiple host devices: 5 simultaneous in Virtual COM, TCP Server, TCP Client mode, UDP
- Versatile Modes: Virtual Com, Serial Tunnel, TCP Server, TCP Client, UDP
- Various Windows O.S. supported: Windows NT/2000/ XP/ 2003/VISTA / Server 2008 / Windows 7 and Windows 8




1.3 Hardware Features

- Built-in HSUPA Cellular Modem with SIM card slot included for WAN connection (IR-710)
- USB port for installing user-selectable 3G USB modem for WAN connection (IR-711UB)
- 10/100Base-T(X) Ethernet ports for LAN connection individually.
- 1 RS-232 Interface
- Power Inputs: 12~48 VDC
- Casing: IP-30
- Operating Temperature: -10 to 60 °C
- Storage Temperature: -40 to 85°C
- Operating Humidity: 5% to 95%, non-condensing

Hardware Installation


2.1 DIN-Rail Installation

IMG-111 has DIN-Rail Kit on rear panel. The DIN-Rail kit helps IMG-111 to fix on the DIN-Rail. It is easy to install the M2M Gateway on the DIN-Rail.



2.2 Wall-Mounted Installation

IMG-111 has another installation method to secure the M2M Gateway. A wall mount panel can be found in the package.



2.3 SIM Card Installation


With IR-710 POWERED DOWN :

1. Un-fasten the screws.
2. Remove the cover.

(NOTE : The cover removal is only for SIM card installation. DO NOT remove the cover in normal operation.)

3. Install SIM card into its slot.
4. Replace the cover.
5. Fasten the screws.


Important Notice: POWER DOWN THE IMG-111 BEFORE INSTALLING SIM CARD.



Hardware Overview

3.1 Front Panel

The following table describes the labels that stick on the IMG-111



1. Fault LED. .
2. Status LED
3. Power LED
4. WAN LED
5. Serial Transmission LED
6. RS-232 Serial port.
7. 10/100Base-T(X) RJ45 fast Ethernet port
8. Reset button
9. 850/900/1800/2100MHz antenna for internal HSUPA modem
10. SIM card slot

3.2 Front Panel

| LED | Color | Status | Description |
|--------|-------|----------------|---|
| PWR | Green | Green On | Power On. |
| Status | Green | Green On | Device Ready |
| | | Green Blinking | Booting up |
| Fault | Amber | Amber On | WAN connection fail (enable event through web) |
| WAN | Green | Green On | Modem Ready |
| | | Green Blinking | Checking Modem status |
| ETH | Amber | Amber On | Port speed to 10Base-T |
| | Green | Green On | Port speed to 100Base-TX |

Cables and Antenna

4.1 Ethernet Cables

The IMG-111 M2M Gateway has one 10/100Base-T(X) Ethernet ports. According to the link type, use CAT 3, 4, 5,5e UTP cables to connect to any other network device (PCs, servers, switches, M2M Gateways, or hubs). Please refer to the following table for cable specifications.

Cable Types and Specifications

| Cable | Type | Max. Length | Connector |
|--------------|----------------------|--------------------|-----------|
| 10Base-T | Cat. 3, 4, 5 100-ohm | UTP 100 m (328 ft) | RJ45 |
| 100Base-T(X) | Cat. 5 100-ohm UTP | UTP 100 m (328 ft) | RJ45 |

4.2 10BASE-T/100BASE-T(X) Pin Assignments

With 10Base-T/100Base-T(X) cable, pins 1 and 2 are used for transmitting data, and pins 3 and 6 are used for receiving data.

RJ45 Pin Assignments



| Pin Number | Assignment |
|------------|------------|
| 1 | TD+ |
| 2 | TD- |
| 3 | RD+ |
| 4 | Not used |
| 5 | Not used |
| 6 | RD- |
| 7 | Not used |
| 8 | Not used |

The IMG-111 M2M Gateways supports auto MDI/MDI-X operation. You can use a straight-through cable to connect PC. The following table below shows the 10Base-T/100Base-T(X) MDI and MDI-X port pin outs.

MDI/MDI-X pins assignment

| Pin Number | MDI port | MDI-X port |
|------------|---------------|---------------|
| 1 | TD+(transmit) | RD+(receive) |
| 2 | TD-(transmit) | RD-(receive) |
| 3 | RD+(receive) | TD+(transmit) |
| 4 | Not used | Not used |
| 5 | Not used | Not used |
| 6 | RD-(receive) | TD-(transmit) |
| 7 | Not used | Not used |
| 8 | Not used | Not used |

Note: "+" and "-" signs represent the polarity of the wires that make up each wire pair.

4.3 Wireless Antenna

850/900/1800/2100MHz antenna is used for built-in HSUPA modem. External RF cable and antenna also can be applied with this connector.




Cellular Antenna

Management Interface

5.1 First-time Installation

Before installing IMG-111 M2M Gateway, you need to access the M2M Gateway by a computer equipped with an Ethernet card. Using an Ethernet card to connect to LAN port is easier and is recommended.



Step 1: Select the Power Source


IMG-111 M2M Gateway can be powered by +12~48V DC power input.

Step 2: Connect a computer to IMG-111

Use either an Ethernet cable to connect to ETH of IMG-111 M2M Gateway to a computer. If the LED of the LAN port lights up, it indicates the connection is established. After that, the computer will initiate a DHCP request to get an IP address from the M2M Gateway.

Step 3: Use the web-based manager to configure IMG-111

The default gateway IP of IMG-111 M2M Gateway is 192.168.10.1. Start the web browser of your computer and type <http://192.168.10.1> in the address box to access the webpage. A login window will popup, and then enter the default login name **admin** and password **admin**.




Login screen

5.2 M2M Gateway Configuration

In this section, the web management page will be explained in detail.

With default setting, you can type <http://192.168.10.1> in the address box of web browser to login the web management interface. A login window will be prompted, enter username **admin** & password **admin** to login.




Login screen

For security reasons, we strongly recommend you to change the password. Click on **System Tools > Login Setting** and change the password.

5.3 Main Interface

The **Home** screen will be shown when login successfully.



Main page

In the main page, you can check the Firmware version, the M2M Gateway running time and the WAN IP setting.

The following table describes the labels in this screen.


| Label | Description |
|----------|--|
| Firmware | Show the current firmware version. |
| Uptime | Show the elapsed time since the AP M2M Gateway is started. |
| Wan IP | Show the WAN IP address. |

5.3.1 Basic Setting

WAN

The IMG-111 M2M Gateway provides Modem/3G connection.

WAN Connection Type: Modem / 3G




Modem/3G Screen

The following table describes the labels in this screen.

| Label | Description |
|---------------|--|
| Phone Number | Telephone number provided by your ISP. |
| APN | Enter the APN value it is optional |
| User Name | User name provided by your ISP. |
| Password | Password provided by your ISP. |
| PIN | Enter the PIN code if PIN check is required. |
| Auto Connect | If this option is enabled, the connection will be called up when M2M Gateway boots up. |
| Device Status | Show the status of built-in HSUPA modem device. |
| Operations | Click " Connect " to call up the built-in HSUPA modem. Click " Disconnect " to shut down the connection. |
| Link Status | Show the status of connection, up , down or connecting . |
| Auto recheck | Enable auto refresh modem status per 28 sec |

LAN

These are the IP settings of the LAN interface for the IMG-111 M2M Gateway. The LAN IP address is privately for your internal network and cannot be exposed on the Internet.



Basic Setting --> LAN

LAN Side settings.

Router Name:

IP Address:

Subnet Mask:

LAN Screen

The following table describes the labels in this screen.

| Label | Description |
|-------------|--|
| IP Address | The IP address of the LAN interface, the default IP address is 192.168.10.1 |
| Subnet Mask | The Subnet Mask of the LAN interface, the default Subnet mask is 255.255.255.0 |

DHCP

DHCP stands for Dynamic Host Control Protocol. The IMG-111 has a built-in DHCP server. The internal DHCP server will assign an IP address to the computers (DHCP client) on the LAN automatically.

Set your computers to be DHCP clients by setting their TCP/IP settings to obtain an IP address automatically. The DHCP server will allocate an unused IP address from the IP address pool to the requesting computer automatically.

1. DHCP Server

Basic Setting --> DHCP --> DHCP Server

Set DHCP Server.

DHCP Server: Enabled Disabled

Starting IP:

Ending IP:

Lease Time: Hours

Local Domain Name: (optional)

Current DHCP Client Information

| # | HostName | Mac | IP | Expires In |
|-----------------------------------|----------|-----|----|------------|
| Static IP Allocation Setup | | | | |

DHCP Server Screen

The following table describes the labels in this screen.

| Label | Description |
|---------------------------------|--|
| DHCP Server | Enable or Disable the DHCP Server. The default setting is Enable |
| Starting IP | The starting IP address of the IP range for the DHCP server |
| Ending IP | The ending IP address of the IP range for the DHCP server |
| Lease Time | The period of time for the IP to be leased. Enter the Lease time. The default setting is 48 hours. |
| Local Domain Name | Enter the local domain name of private network. It is optional. |
| Current DHCP Client Information | List of the computers on your network that are assigned an IP address by internal DHCP server. |

2. IP Allocation

The IP Allocation provides one-to-one mapping of MAC address to IP address. When computers with the MAC address requesting an IP from the IMG-111 M2M Gateway, it will be assigned with the IP address according to the mapping. You can choose one from the client lists and add it to the mapping relationship.

Basic Setting --> DHCP --> IP Allocation

Allocate IP Address Manually.

-- Choose a Client to Edit --

| MAC Address | IP Address | | |
|----------------------|----------------------|------------------------------------|--------------------------------------|
| <input type="text"/> | <input type="text"/> | <input type="button" value="Add"/> | <input type="button" value="Clear"/> |

Static DHCP Client List:

| # | MAC Address | IP Address | Operations |
|---|-------------|------------|------------|
| | | | |

IP Allocation Screen

The following table describes the labels in this screen.

| Label | Description |
|-------------------------|---|
| Choose a Client to Edit | The list shows the MAC addresses and IP addresses that are already assigned by IMG-111. Choose one from the list and click Copy to button for editing. |
| MAC Address | The MAC addresses of the computer. |
| IP Address | The IP address to be related to the MAC address. |
| Static DHCP Client List | The list shows the MAC address and IP address one-to-one relationship. |

5.3.2 Serial Setting.

Remote management

The Remote management setting allow user to enable the WAN access of the DS-tool management and Serial port access

Ser2net Setting -->Remote management

Set the Remote Management enable DS-tool to access from WAN.

Remote management: Enable Disable

Port External Access:

Port1: Enable Disable

The following table describes the labels in this screen.

| Label | Description |
|----------------------|---|
| Remote Management | Enable to managed IMG-111 by DS-tool through WAN access |
| Port External Access | Enable to allow using of serial data port and control port through WAN access I |

Serial Configuration

Ser2net Setting --> Serial Configuration

| | |
|--|---|
| | Port1 |
| Port Alias | <input type="text" value="Port1"/> |
| Interface | RS232 |
| Baud Rate | 38400 |
| Data Bits | 8 |
| Stop Bits | 1 |
| Parity | None |
| Flow Control | None |
| Force TX Interval Time | <input type="text" value="0"/> ms |
| Performance | <input checked="" type="radio"/> Throughput <input type="radio"/> Latency |
| <input type="button" value="Apply"/> <input type="button" value="Cancel"/> | |

The following table describes the labels in this screen.

| Label | Description |
|------------------------|---|
| Port Alias | Remark the port to hint the connected device. |
| Interface | RS422 / RS485(2-wires) / RS485(4-wires) |
| Baud rate | 110bps/300bps/1200bps/2400bps/4800bps/9600bps/19200bps/ 38400bps/57600bps/115200bps |
| Data Bits | 5, 6, 7, 8 |
| Stop Bits | 1, 2 (1.5) |
| Parity | No, Even, Odd, Mark, Space |
| Flow Control | No, XON/XOFF |
| Force TX Interval Time | Force TX interval time is to specify the timeout when no data has been transmitted. When the timeout is reached or TX buffer is full (4K Bytes), the queued data will be sent. 0 means disable. Factory default value is 0. |
| Performance | Throughput: This mode optimized for highest transmission speed. Latency: This mode optimized for shortest response time. |

Port Profile


Ser2net Setting --> Port Configuration

| | |
|-------------------------|---|
| | Port1 |
| Local TCP Port | <input type="text" value="4008"/> |
| Command Port | <input type="text" value="4009"/> |
| Mode | Serial to Ethernet |
| Flush Data Buffer After | <input type="text" value="0"/> ms |
| Delimiter(Hex 0~ff) | 1: <input type="text" value="00"/> 2: <input type="text" value="00"/> 3: <input type="text" value="00"/> 4: <input type="text" value="00"/> |
| Mode | Ethernet to Serial |
| Flush Data Buffer After | <input type="text" value="0"/> ms |
| Delimiter(Hex 0~ff) | 1: <input type="text" value="00"/> 2: <input type="text" value="00"/> 3: <input type="text" value="00"/> 4: <input type="text" value="00"/> |

| Label | Description |
|--------------------|--|
| Serial to Ethernet | <p>Flush Data Buffer After:</p> <p>The received data will be queued in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "flush S2E data buffer" timeout, the data will also be sent. You can set the time from 0 to 65535 seconIMG.</p> <p>Delimiter:</p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option "Flush Serial to Ethernet data buffer" times out. 0 means disable. Factory default is 0</p> |
| Ethernet to serial | <p>Flush Data Buffer After:</p> <p>The received data will be queued in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "flush E2S data buffer" timeout, the data will also be sent. You can set the time from 0 to 65535 seconIMG.</p> <p>Delimiter:</p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option "Flush Ethernet to Serial data buffer" times out. 0 means disable. Factory default is 0</p> |

Service Mode – Virtual COM Mode

In Virtual COM Mode, the driver establishes a transparent connection between host and serial device by mapping the Port of the serial server serial port to local COM port on the host computer. Virtual COM Mode also supports up to 5 simultaneous connections, so that multiple hosts can send or receive data by the same serial device at the same time.



| Ser2net Setting --> Service Mode | |
|--|---|
| | Port1 |
| Data Encryption | <input type="radio"/> Enable <input checked="" type="radio"/> Disable |
| Service Mode | Virtual COM Mode |
| Idle Timeout | 10 (0~65535)seconds |
| Alive Check | 20 (0~65535)seconds |
| Max Connection | 1 max. connection (1~5) |
| <input type="button" value="Apply"/> <input type="button" value="Cancel"/> | |

The following table describes the labels in this screen.

| Label | Description |
|-----------------|---|
| Data Encryption | Use SSL to encrypt data. |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Max Connection | The number of Max connection can support simultaneous connections are 5, default values is 1. |

*Not allowed to mapping Virtual COM from web

Service Mode – TCP Server Mode

In TCP Server Mode, IMG is configured with a unique Port combination on a TCP/IP network. In this case, IMG waits passively to be contacted by the device. After the device establishes a connection with the serial device, it can then proceed with data transmission. TCP Server mode

also supports up to 5 simultaneous connections, so that multiple device can receive data from the same serial device at the same time.

Ser2net Setting --> Service Mode

| | |
|-----------------|---|
| | Port1 |
| Data Encryption | <input type="radio"/> Enable <input checked="" type="radio"/> Disable |
| Service Mode | TCP Server Mode ▾ |
| TCP Server Port | 4008 |
| Idle Timeout | 10 (0~65535)seconds |
| Alive Check | 20 (0~65535)seconds |
| Max Connection | 1 ▾ max. connection(1~5) |

Apply Cancel

The following table describes the labels in this screen.

| Label | Description |
|-----------------|---|
| Data Encryption | Use SSL to encrypt data. |
| TCP Server Port | Set the port number for data transmission. |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Max Connection | The number of Max connection can support simultaneous connections are 5, default values is 1. |

Service Mode – TCP Client Mode

In TCP Client Mode, device can establish a TCP connection with server by the method you set (Startup or any character). After the data has been transferred, device can disconnect automatically from the server by using the TCP alive check time or Idle timeout settings.

Ser2net Setting --> Service Mode

| | |
|------------------|--|
| Port1 | |
| Data Encryption | <input type="radio"/> Enable <input checked="" type="radio"/> Disable |
| Service Mode | TCP Client Mode |
| Destination Host | 0.0.0.0 : 4008 |
| Idle Timeout | 10 (0~65535)seconds |
| Alive Check | 20 (0~65535)seconds |
| Connect on | <input checked="" type="radio"/> Startup <input type="radio"/> Any Character |
| Destination Host | Port |
| 1. | 65535 |
| 2. | 65535 |
| 3. | 65535 |
| 4. | 65535 |

Apply Cancel

The following table describes the labels in this screen.

| Label | Description |
|--------------------------|---|
| Data Encryption | Use SSL to encrypt data. |
| Destination Host | Set the IP address of host and the port number of data port. . |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Connect on Startup | The TCP Client will build TCP connection once the connected serial device is started. |
| Connect on Any Character | The TCP Client will build TCP connection once the connected serial device starts to send data. |

Service Mode – UDP Client Mode

Compared to TCP communication, UDP is faster and more efficient. In UDP mode, you can Uni-cast or Multi-cast data from the serial device server to host computers, and the serial device can also

receive data from one or multiple host

Ser2net Setting --> Service Mode

| | | |
|-------------------------|----------------------|-----------|
| Port1 | | |
| Service Mode | UDP Mode | |
| Listen Port | 4008 | |
| Host start IP | Host end IP | Send Port |
| 1. <input type="text"/> | <input type="text"/> | 65535 |
| 2. <input type="text"/> | <input type="text"/> | 65535 |
| 3. <input type="text"/> | <input type="text"/> | 65535 |
| 4. <input type="text"/> | <input type="text"/> | 65535 |

Apply Cancel

5.3.3 Advanced Settings

NAT Setting

1. Virtual Server

Virtual Server is used for setting up public services on the LAN, such as DNS, FTP and Email. Virtual Server is defined as a Local Port to the LAN servers, and all requests from Internet to this Local port will be redirected to the computer specified by the Local IP. Any PC that was used for a virtual server must have static or reserved IP Address because its IP address may change when requesting IP by DHCP.

Advanced Setting --> NAT Setting -> Virtual Server

Virtual server settings.

Virtual Server: Enable Disable

Description:

Public IP: All Specify

Public Port:

Protocol: TCP UDP Both

Local IP:

Local Port:

Enable Now: Yes No

Add Cancel

Virtual server list:

| # | Description | Public IP | Public Port | Protocol | Local IP | Local Port | Enabled | Ops |
|---|-------------|-----------|-------------|----------|----------|------------|---------|-----|
|---|-------------|-----------|-------------|----------|----------|------------|---------|-----|

Virtual Server

The following table describes the labels in this screen.

| Label | Description |
|---------------------|--|
| Virtual Server | Enable or disable Virtual Server. |
| Description | Enter the description of the entry. Acceptable characters consist of '0-9', 'a-z', 'A-Z'. This field accepts null value. |
| Public IP | Enter the public IP that is allowed to access the virtual service, if not specified, choose All. |
| Public Port | The port number on the WAN (Wide Area Network) side that will be used to access the virtual service. |
| Protocol | The protocol used for the virtual service. |
| Local IP | The IP of the computer that will be providing the virtual service. |
| Local Port | The port number of the service used by the Private IP computer. |
| Enable Now | Enable the virtual server entry after adding it. |
| Virtual server list | Click Edit to edit the virtual service entry, Del to delete the entry. |

2. Port Trigger

Some applications require multiple connections, like Internet games, video conferencing, Internet calling and so on. These applications cannot work with a pure NAT M2M Gateway. Port Trigger is used for some of the applications that can work with an NAT M2M Gateway.

Advanced Setting --> NAT Setting -> Port Trigger

Port Trigger settings.

Port Trigger: Enable Disable

Description:

Trigger Port:

Trigger Protocol: TCP UDP Both

Incoming Port:

Incoming Protocol: TCP UDP Both

Enable: Yes No

Port Trigger List:

| # | Description | Trigger Protocol | Trigger Port | Incoming Protocol | Incoming Port | Enable | Ops |
|---|-------------|------------------|--------------|-------------------|---------------|--------|-----|
|---|-------------|------------------|--------------|-------------------|---------------|--------|-----|

Port Trigger Screen

The following table describes the labels in this screen.

| Label | Description |
|--------------|--|
| Port Trigger | Enable or disable Port Trigger. |
| Description | This is the description for the entry. |

| | |
|-------------------|--|
| Trigger Port | This is the port used to trigger the application. |
| Trigger Protocol | This is the protocol used to trigger the application. |
| Incoming Port | This is the port number on the WAN side that will be used to access the application. |
| Enable | Enable the rule after adding the entry. |
| Port Trigger List | Click Edit to edit the entry, click Del to delete the entry. |

3. DMZ

It allows a computer to be exposed to the Internet. This feature is useful for gaming purposes.

Enter the IP address of the internal computer that will be the DMZ host. Adding a client to the DMZ may expose your local network with variety of security risks, so only use this option carefully.

Advanced Setting --> NAT Setting -> DMZ

DMZ settings.

DMZ: Enable Disable

Description:

DMZ Host IP:

DMZ Screen

The following table describes the labels in this screen.

| Label | Description |
|-------------|--|
| DMZ | Enable or disable the DMZ. |
| Description | Description for the DMZ host entry. |
| DMZ Host IP | Enter the IP address of the computer to be in the DMZ. |

4. UPnP

The UPnP (Universal Plug and Play) feature allows the devices, such as Internet computers, to access the local host resources or devices as needed. UPnP devices can be automatically discovered by the UPnP service application on the LAN.

Advanced Setting --> NAT Setting -> UPnP

UPnP settings.

UPnP: Enabled Disabled
 Enable NAT-PMP

UPnP List:

| # | Application | Ext Port | Protocol | Int Port | IP Address |
|---|-------------|----------|----------|----------|------------|
| | | | | | |

UPnP Screen

The following table describes the labels in this screen.

| Label | Description |
|----------------|---|
| UPnP | Enable or disable UPnP. |
| Enable NAT-PMP | NAT-PMP allows a computer in a private network (behind a NAT M2M Gateway) to automatically configure the M2M Gateway to allow parties outside the private network to contact with each other. NAT-PMP operates with UDP. It essentially automates the process of port forwarding. Check the box to enable NAT-PMP. |
| UPnP List | This table lists the current auto port forwarding information. Application: The application that generates this port forwarding. Ext Port: The port opened on WAN side. Protocol: The protocol type. Int Port: The port redirected to the local computer. IP Address: The IP address of local computer to be redirected to. Status: This status shows if the entry is valid or not. |

Security Setting

1. IP Filter

Filters are used to deny or allow LAN computers from accessing the internet. It also allows or denies WAN hosts to access LAN computers.

Advanced Setting --> Security Setting --> IP Filter

IP filter settings.

IP Filter: Enable Disable

Description:

Rule:

Direction:

IP Address: Source IP:
Destination IP:

Protocol: All
 ICMP
 Specify protocol number:
 TCP Specify port:
 UDP Specify port:

Enable Now: Yes No

IP filter list:

| # | Description | Rule | Direction | Source IP | Destination IP | Protocol | Port | Enabled | Operations |
|---|-------------|------|-----------|-----------|----------------|----------|------|---------|------------|
|---|-------------|------|-----------|-----------|----------------|----------|------|---------|------------|

IP Filter Screen

The following table describes the labels in this screen.

| Label | Description |
|----------------|--|
| IP Filter | Enable or disable the IP Filter. |
| Description | Enter description for the entry. |
| Rule | Select DROP, ACCEPT and REJECT rule for the entry. |
| Direction | Specify the direction of the data flow that is to be filtered. |
| IP Address | Enter the IP address of the source and destination computer. |
| Protocol | Choose which protocol to be filtered. |
| Enable Now | Enable the entry after adding it. |
| IP filter list | Click edit for editing the entry, click Del to delete the entry. |

2. MAC Filter

Filters are used to deny or allow LAN computers from accessing the internet, according to their MAC address.

Advanced Setting --> Security Setting --> MAC Filter

MAC Filter settings.

MAC Filter: Enable Disable

Description:

Rule:

MAC Address: (e.x. 00:11:22:aa:bb:cc)

Enable Now: Yes No

MAC filter list:

| # | Description | Rule | MAC Address | Enabled | Operations |
|---|-------------|------|-------------|---------|------------|
|---|-------------|------|-------------|---------|------------|

MAC Filter Screen

The following table describes the labels in this screen.

| Label | Description |
|----------------|--|
| MAC Filter | Enable or disable the MAC Filter. |
| Description | Enter the description for the entry. |
| Rule | Select DROP, ACCEPT and REJECT rule for the entry. |
| MAC Address | Enter the MAC address to be filtered. |
| Enable Now | Enable the entry after adding it. |
| IP filter list | Click Edit for editing the entry, click Del to delete the entry. |

VPN Setting

VPN Setting is settings that are used to create virtual private tunnels to remote VPN gateways. The tunnel technology supports data confidentiality, data origin, authentication and data integrity of network information by utilizing encapsulation protocols, encryption algorithms, and hashing algorithms.

1. Open VPN

Open VPN is a full-functioned SSL VPN solution which can accommodates a wide range of configurations including remote access, site-to-site VPNs, WiFi security, and enterprise-scale remote access solutions with load balancing, failover, and fine-grained access-controls.

Advanced Setting --> Vpn Setting -> Openvpn

Openvpn settings.

Server settings.

Openvpn Server: Enable Disable

Tunnel Protocol:

Port:

LZO Compression: Enable Disable

Keys Setting:

Client settings.

Openvpn Client: Enable Disable

Server IP :

Tunnel Protocol:

Port:


LZO Compression: Enable Disable

Keys Setting:

Open VPN Screen

The following topology shows the common use of VPN connection from WAN side.

1: Open VPN Server



Connection to Open VPN Server

Before connecting to the Open VPN server of IMG-111 M2M Gateway, please install Open VPN client software for your windows PC. It can be downloading from <http://OpenVPN.net/download.html#stable>. The current version of Open VPN used in IMG-111 is



version 2.0.9. The corresponding software for client should be installed.

The following table describes the labels in this screen.

| Label | Description |
|-----------------|---|
| Open VPN Server | Enable or disable the function of Open VPN Server. |
| Tunnel Protocol | Select UDP or TCP protocol. |
| Port | Input the number about the port, and the default is 1194. |
| LZO Compression | Enable or disable the function of LZO Compression. |
| Keys Setting | Select Auto to use the preset certificates, select Manual to paste your certificates. Please install Open VPN client software to generate your certificates and paste them here. For more information, please visit Open VPN website. |


2: Open VPN Client

Two M2M Gateways are needed for creating site-to-site VPN connection using this mode.

The following table describes the labels in this screen.

| Label | Description |
|-----------------|---|
| Open VPN Client | Enable or disable the function of Open VPN Client. You can allow or deny the Open VPN Client with this option. |
| Server IP | Enter the Open VPN Server IP address. |
| Tunnel Protocol | Select UDP or TCP protocol. |
| Port | Enter the port number, default is 1194. |
| LZO Compression | Enable or disable the LZO Compression. |
| Keys Setting | Select Auto to use the preset certificates, select Manual to paste your certificates. Please install software for Open VPN client to generate your certificates and paste them here. For more information, please visit Open VPN website. |

3: Open VPN Server VS Client



The chart above displays the connection of Open VPN Server and Client. The Server IP and Client IP address should configure with the same network domain.

2. PPTP VPN

The PPTP (Point to Point Tunneling Protocol) VPN feature allows PC connected to the M2M Gateway from WAN port, just like connecting in the LAN. To create a PPTP connection to the M2M Gateway, you should create a PPTP network connection if you are using a window PC. The steps are: **Right click Network > property > create a new connection > connect to my work space (VPN) > use VPN to internet > enter the user name and password** which are set in the page.

Advanced Setting --> Vpn Setting -> PPTP Vpn

PPTP Server settings.

PPTP Server: Enable Disable

Server IP:

Clients IP:

PPP Options:


- require-chap
- require-mschap
- require-mschap-v2
- require-mppe

Routing Option: Enable Routing Protocols through PPTP VPN Connection

CHAP-Secrets:

PPTP VPN Screen

The following topology shows the common use of PPTP connection from the internet.



Connection to PPTP VPN Server

The following table describes the labels in this screen.

| Label | Description |
|-------------|--|
| PPTP Server | Enable or disable PPTP VPN Server. |
| Server IP | Enter the server side IP address, default is the LAN port IP. |
| Client IP | Enter the IP address range, format is as 192.168.10.xx-xx, connected |

| | |
|--------------|--|
| | client will be assigned the IP address. |
| CHAP-Secrets | Enter the username and password pairs, format is as user * pass *, multiple username password pairs are allowed. |

3. PPTP Client

If the M2M Gateway A want to link with the others which is not in the same network with the M2M Gateway A, the function of PPTP client should support in the M2M Gateway page.

Advanced Setting --> Vpn Setting -> PPTP Client

PPTP Client settings.

PPTP Client: Enable Disable

Server IP/Hostname:

Username:

Password:

Options:


- Reconnect on failure
- default route
- require-chap
- require-mschap
- require-mschap-v2
- require-mppe

Routing Option: Enable Routing Protocols through PPTP Client Connection

Operations:

Link Status: Disconnected

PPTP client settings screen



The following table describes the labels in this screen.

| Label | Description |
|--------------------|---|
| PPTP Client | Enable or disable PPTP Client. |
| Server IP/Hostname | Enter the server IP address or hostname. |
| Username/Password | Enter the username and password which is signed by PPTP server. |
| Option | Reconnect on failure: Pitch on this option, it will be reconnect when the link is on failure. Require MPPE: Choose Enable Require MPPE (Microsoft Point-to-Point Encryption) to encrypt data across Point-to-Point Protocol (PPP) and Virtual Private Network links. |
| Operations | Click "Connect" to link the server, if or not, you can click ""Disconnect" to break off from the server. |
| Link Status | Show the status about the link. |

Routing Protocol (Routing Setting)

This page shows the information of routing table. The initial state of the M2M Gateway connect to the WAN, it will be based on the outside networks to access the routing table automatically. You can refer the shows about the bellow page.

Current Routing Table:

| Destination | Gateway | Subnet Mask | Metric | Interface |
|--------------|---------|---------------|--------|--------------|
| 192.168.10.0 | 0.0.0.0 | 255.255.255.0 | 0 | br0(LAN) |
| 127.0.0.0 | 0.0.0.0 | 255.0.0.0 | 0 | lo(LOOPBACK) |

The table shows the normal routing table

1. Use Dynamic Routing

Use the dynamic routing, you should not choose "Disable" about the **RIPv1 & v2** in the M2M Gateways.

Click "Apply", and you can see the more information in the **Current Routing Table**, which shows the network segment of the other M2M Gateway.

Advanced Setting --> Routing Protocol -> Routing Setting

Current Routing Table:

| Destination | Gateway | Subnet Mask | Metric | Interface |
|--------------|---------|---------------|--------|--------------|
| 192.168.10.0 | 0.0.0.0 | 255.255.255.0 | 0 | br0(LAN) |
| 127.0.0.0 | 0.0.0.0 | 255.0.0.0 | 0 | lo(LOOPBACK) |

Static Route Entry:

| Destination | Gateway | Subnet Mask | Metric | Interface | Operations |
|----------------------|----------------------|----------------------|----------------------|-----------|------------------------------------|
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> | WAN | <input type="button" value="Add"/> |

Mode:

RIPv1 & v2:

Telnet Setting: Enable Disable

Port:

Password:

Routing setting screen

The following table describes the labels in this screen.

| Label | Description |
|-----------------------|---|
| Current Routing Table | Show the current the routing information. |
| Static Route Entry | Not RIP and enter the right value in the textbox will be showing. |

| | |
|----------------|---|
| Mode | If you want to the PC in the M2M Gateway can visit the outside network, only choose the Gateway Mode; if or not, you choose the M2M Gateway Mode. |
| RIPv1 &v2 | Choose "Disable" in the Static routing. |
| Telnet Setting | Only use in the Dynamic routing. |

2. Use Static Routing

Use the Static routing, you should choose "Disable" about the **RIPv1 & v2** in the M2M Gateways.

Click "Apply", and you can see the more information in the **Current Routing Table** and **Static Route Entry**, which shows the network segment of the other M2M Gateway.

Advanced Setting --> Routing Protocol -> Routing Setting

Current Routing Table:

| Destination | Gateway | Subnet Mask | Metric | Interface |
|--------------|---------|---------------|--------|--------------|
| 192.168.10.0 | 0.0.0.0 | 255.255.255.0 | 0 | br0(LAN) |
| 127.0.0.0 | 0.0.0.0 | 255.0.0.0 | 0 | lo(LOOPBACK) |

Static Route Entry:

| Destination | Gateway | Subnet Mask | Metric | Interface | Operations |
|--------------|---------|---------------|--------|-----------|---------------|
| 192.168.11.0 | 0.0.0.0 | 255.255.255.0 | 0 | WAN | Commit Delete |

| Destination | Gateway | Subnet Mask | Metric | Interface | Operation |
|----------------------|----------------------|----------------------|----------------------|-----------|-----------|
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> | WAN | Add |

Mode: Gateway

RIPv1 & v2: Disable


Telnet Setting: Enable Disable

Port: 23

Password:

Static route setting screen

Use the dynamic routing; it will have many ways such as RIP, OSPF.BGP. In this M2M Gateway, we use the RIP Protocol to finish the dynamic routing table.




The Routing Topography

RIP, Routing Information Protocol, is a dynamic routing protocol used in local and wide area networks. As such it is classified as an interior gateway protocol (IGP) using the distance-vector routing algorithm.

After all settings, PC1 can visit PC2 which is different network segment of the PC1.

Miscellaneous DDNS

Dynamic Domain Name Server is to keep a domain name linked to a dynamic IP address.



DDNS Screen

For example, Choose DDNS Service: www.3322.org and configure the following instructions:


The following table describes the labels in this screen.

| Label | Description |
|--------------|---|
| User Name | Enter the user name for your DDNS account. |
| Password | Enter the password for your DDNS account. |
| Domain | Enter the domain names provided by your dynamic DNS service provider. |
| Mail Server | Enter the mail server if provided. |
| Use Wildcard | Check the box the enable wildcard option. |

5.3.4 System Tools

Date & Time

In this page, you can set the date & time of the device. The correct date & time will be helpful for logging of system events. A NTP (Network Time Protocol) client can be used to synchronize date & time with NTP server through internet.



The screenshot shows the 'System Tools --> Date & Time' configuration page. It includes fields for 'Local Date' (Year: 2010, Month: 1, Day: 1), 'Local Time' (Hour: 0, Minute: 20, Second: 58), and 'Time Zone' (GMT+08:00). There is a button 'Get Current Date & Time from Browser'. Under 'NTP', the 'Enable' checkbox is checked, with 'NTP Server 1' set to 'pool.ntp.org' and 'NTP Server 2' set to 'time.nist.gov (optional)'. The 'Synchronise' dropdown is set to 'Every Day' at '00:00'.

Date & Time Screen

The following table describes the labels in this screen.

| Label | Description |
|------------|-------------------------------|
| Local Date | Set local date manually. |
| Local Time | Set local time manually. |
| Time Zone | Select the time zone manually |

| | |
|--------------------------------------|---|
| Get Current Date & Time from Browser | Click this button; you can set the time from your browser. |
| NTP | Enable or disable NTP function to synchronize time from the NTP server. |
| NTP Server 1 | The primary NTP Server. |
| NTP Server 2 | The secondary NTP Server. |
| Synchronize | This is the scheduled time when the NTP synchronization performed. |

System Event

When the WAN Link Down is triggered, the notification procedure will be performed

System Tools --> System Event

WAN Link Down Alarm

Disable WAN Link Down Alarm
 Enable WAN Link Down Alarm

Login Setting

At this page, the administrator can change the login name and password. The default name and password is **admin** and **admin**.

System Tools --> Login Setting

Login settings.

Old Login Name: admin

Old Password:

New Login Name:

New Password:

Confirm New Password:

Web Protocol: HTTP HTTPS

Port:

Login Setting Screen

The following table describes the labels in this screen.

| Label | Description |
|----------|--------------------------------------|
| Old Name | This field shows the old login name. |

| | |
|----------------------|---|
| Old Password | Before making a new setting, you should provide the old password for verification. Acceptable characters of this field contains '0-9', 'a-z', 'A-Z' and must be between 0 to 15 characters in length. An empty password is also acceptable. |
| New Name | Enter a new login name. Acceptable characters of this field contains '0-9', 'a-z', 'A-Z' and must be between 1 to 15 characters in length. An empty name is not acceptable. |
| New Password | Enter a new login password. Acceptable characters of this field contains '0-9', 'a-z', 'A-Z' and must be between 0 to 15 characters in length. |
| Confirm New Password | Retype the password to confirm it. Acceptable inputs of this field contains '0-9', 'a-z', 'A-Z' and must be between 0 to 15 characters in length. |
| Web Protocol | Choose the web management page protocol. HTTP and HTTPS are both supported. |
| Port | Choose the web management page port number. For HTTP, default port is 80; For HTTPS, default port is 443. |

HTTPS (HTTP over SSL) is a Web protocol which encrypts and decrypts user page requests as well as the pages that are returned by the Web server.

M2M Gateway Restart

If you want restart the M2M Gateway through the **Warm Reset**, click **Restart Now** to restart the Wireless M2M Gateway. Also, you can set a **Scheduling** time to make the M2M Gateway restart.

System Tools --> Router Restart


Router Restart Utility.

Scheduling: Enable

Restart at :

M2M Gateway Restart Screen

Firmware Upgrade




The screenshot shows the 'System Tools --> Firmware Upgrade' interface. At the top, it says 'System Tools --> Firmware Upgrade'. Below that is a red warning: 'Do NOT power off the router while upgrading!'. The current firmware version is listed as '1.0i'. There is a text input field for the firmware file path, followed by a '瀏覽...' (Browse) button. Below the input field is a 'Start Upgrade' button.

Firmware Upgrade Screen

Newer firmware may provide better performance or function extensions. To upgrade the new firmware, you need a firmware file which matches the model of this AP M2M Gateway. It will take several minutes to upload and update the firmware. After the upgrade is done successfully, reboot the M2M Gateway to utilize new firmware.

Important Notice: DO NOT POWER OFF THE M2M GATEWAY OR PRESS THE RESET BUTTON WHILE THE FIRMWARE IS BEING UPGRADED.

Save/Restore Configurations



The screenshot shows the 'System Tools --> Save/Restore Configurations' interface. At the top, it says 'System Tools --> Save/Restore Configurations'. Below that is the text 'Save/Restore Configurations.'. There are three main sections: 1. 'Save Current Configurations' with a 'Save' button. 2. 'Restore previous saved configurations' with a text input field, a '瀏覽...' (Browse) button, and a 'Restore' button. 3. 'Restore factory default settings' with a 'Restore Factory Default Settings' button.

Save/Restore Configurations Screen

Save: The configuration file can be downloaded. (Internet Explorer user will need to click on the protection bar on top and click choose "download files")

The following table describes the labels in this screen.

| Label | Description |
|--------------------------|---|
| Download configuration | The current system settings can be saved as a file into your PC. |
| Upload configuration | The configuration can be restored to the M2M Gateway. To reload a system settings file, click on Browse to browse your local hard drive and locate the system settings file previously saved. Click Upload when you have selected the file. |
| Restore Default Settings | You may also reset the M2M Gateway to the factory settings by clicking on Restore Default Settings. The M2M Gateway will reboot to validate the default settings. |

Remote management

Set the Remote Management to access the M2M Gateway web pages from WAN side.

System Tools --> Remote Management

Set the Remote Management to access the Router web pages from WAN side.

Remote Management: Enable Disable

Management Port:

Permission: Any Host

Host with IP address:

Host within IP range: -

Miscellaneous (Ping)

System Tools --> Miscellaneous

Miscellaneous utilities.

Ping Test: Destination:

Ping Test Result:

Miscellaneous Screen

The Ping Test is used to send Ping packets to test if a computer whether it is on the Internet or test if the WAN connection is OK. Enter a domain or IP in the destination box and click Ping to test.

5.3.5 System Status

System Info

System Status --> System Info

System Info.

| | | |
|---------------------------|---------------------------|-------------------|
| Model: | IMG-111 | |
| Model Description: | M2M 1 Port Serial Gateway | |
| WAN: | Mode | Modem/3G |
| | | |
| LAN: | IP Address | 192.168.10.1 |
| | Subnet Mask | 255.255.255.0 |
| | MTU | 1500 |
| | MAC Address | 00:32:12:31:31:31 |
| | DHCP Server | Enabled |

System Info Screen

This page displays the details information for the M2M Gateway including model name, model description, firmware version, WAN, LAN settings.

System Log

System Status --> System Log

System log.

| Log Option: | <input type="checkbox"/> DHCP Server | <input type="checkbox"/> Boot Message | | | |
|--------------------|--|---------------------------------------|---------|-----------|------|
| | <input type="checkbox"/> NTP Client | <input type="checkbox"/> UPNP | | | |
| | <input type="checkbox"/> Firewall | <input type="checkbox"/> Modem | | | |
| | <input type="button" value="Select All"/> <input type="button" value="Deselect All"/> <input type="button" value="Save Option"/> | | | | |
| | System Log: <input type="button" value="Refresh"/> <input type="button" value="Clear Logs"/> | | | | |
| | <table border="1"><thead><tr><th>#</th><th>Date Time</th><th>Item</th><th>Content</th></tr></thead></table> | | # | Date Time | Item |
| # | Date Time | Item | Content | | |

System Log Screen

The M2M Gateway keeps a running log of events and activities occurring on the M2M Gateway, several filters are provided for displaying related log entries.

Click the button '**Refresh**' to refresh the page.

Click the button '**Clear Logs**' to clear the log entries.

Traffic Statistics

System Status --> Traffic Statistics

Traffic statistics.

| Interface | Send | Receive |
|-----------|-----------------------------|-----------------------------|
| LAN | 592916 Bytes (1433 Packets) | 178571 Bytes (1468 Packets) |
| WAN | 0 Bytes (0 Packets) | 0 Bytes (0 Packets) |

Traffic Statistics Screen


This page displays the network traffic statistics for both received and transmitted packets through the Ethernet port and wireless connections.

5.4 DS-tool

The IMG basic information and some serial port related function can be configure by using DS-tool, including the VCOM Mapping

General settings

This page display some basic information of the device and also includes the setting of device name.



The screenshot shows the 'General' tab of the DS-tool interface. It contains the following fields and values:


- Model: IMG-111
- LAN IP Address: 192.168.10.1
- LAN MAC Address: 00:32:12:31:31:31
- Version: 1.0g
- Device Name/Location: IMG-111313131

At the bottom of the form, there are three buttons: 'Refresh', 'Apply Only', and 'Apply and Save'.

The following table describes the labels in this screen.

| Label | Description |
|----------------------|---------------------|
| Device Name/location | set the device name |


Security



The following table describes the labels in this screen.

| Label | Description |
|------------------|-----------------------|
| Password setting | Changing new password |


Network Setting



The following table describes the labels in this screen.

| Label | Description |
|-------------|--|
| LAN IP | Assigning an IP address. |
| Subnet Mask | All devices on the network must have the same subnet mask to communicate on the network. |

Upgrade Firmware



The following table describes the labels in this screen.

| Label | Description |
|---------|------------------------------|
| Upgrade | Enable the firmware upgrade. |

Save/Load




General | Security | Ethernet | Upgrade Firmware | **Reboot Device**

Reboot Device

The following table describes the labels in this screen.

| Label | Description |
|---------------|----------------------------------|
| Reboot Device | Reboot the IMG-111 (warm start). |

Serial Settings



Serial Settings | **Service Mode**

port1

Port Alias

Baudrate Stop Bits Performance

Parity Flow Control

Data Bits Interface

Delimiter Settings

Serial to Ethernet | **Ethernet to Serial**

Delimiter 1 (HEX) Enabled

Delimiter 2 (HEX) Enabled

Delimiter 3 (HEX) Enabled

Delimiter 4 (HEX) Enabled

Flush Ethernet to Serial Data Buffer After

(0-65535) ms

The received data will be queuing in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "flush E2S data buffer" timeout, the data will also be sent.


The following table describes the labels in this screen.



| Label | Description |
|------------------------|---|
| Port Alias | Remark the port to hint the connected device. |
| Interface | RS232 |
| Baud rate | 110bps/300bps/1200bps/2400bps/4800bps/9600bps/19200bps/ 38400bps/57600bps/115200bps |
| Data Bits | 5, 6, 7, 8 |
| Stop Bits | 1, 2 (1.5) |
| Parity | No, Even, Odd, Mark, Space |
| Flow Control | No, XON/XOFF |
| Performance | Throughput: This mode optimized for highest transmission speed. Latency: This mode optimized for shortest response time. |
| Serial to Ethernet | <p>Delimiter: You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option–“Flush Serial to Ethernet data buffer” times out. 0 means disable. Factory default is 0.</p> <p>Flush Data Buffer After: The received data will be queuing in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after “flush S2E data buffer” timeout the data will also be sent. You can set the time from 0 to 65535 seconIMG.</p> |
| Ethernet to Serial | <p>Delimiter: You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option “Flush Ethernet to Serial data buffer” times out. 0 means disable. Factory default is 0.</p> <p>Flush Data Buffer After: The received data will be queuing in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after “flushE2S data buffer” timeout the data will also be sent. You can set the time from 0 to 65535 seconIMG.</p> |
| Force TX Interval Time | Force TX interval time is to specify the timeout when no data has been transmitted. When the timeout is reached or TX buffer is full (4K Bytes), the queued data will be sent. 0 means disable. Factory default value is 0. |

Service Mode – Virtual COM Mode

In Virtual COM Mode, The driver establishes a transparent connection between host and serial device by mapping the Port of the serial server serial port to local COM port on the host computer. Virtual COM Mode also supports up to 5 simultaneous connections, so that multiple hosts can send or receive data by the same serial device at the same time.



The following table describes the labels in this screen.

| Label | Description |
|---------------------|--|
| Encryption with SSL | Use SSL to encrypt data. |
| Map Virtual COM | Select a Virtual COM Name to map on. |
| Max Connection | The number of Max connection can support simultaneous connections are 5, default values is 1. |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this |

| | |
|-------------|---|
| | setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |

*Not allowed to mapping Virtual COM from web

Service Mode – TCP Server Mode

In TCP Server Mode, IMG is configured with a unique Port combination on a TCP/IP network. In this case, IMG waits passively to be contacted by the device. After a connection is established, it can then proceed with data transmission. TCP Server mode also supports up to 5 simultaneous connections, so that multiple device can receive data from the same serial device at the same time.




Figure 5-16 TCP Server mode

The following table describes the labels in this screen.



| Label | Description |
|---------------------|---|
| Encryption with SSL | Use SSL to encrypt data. |
| Data Port | Set the port number for data transmission. |
| Auto Scan | Scan the data port automatically. |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Max Connection | The number of Max connection can support simultaneous connections are 5, default values is 1. |

Table 5-11 TCP Server mode

Service Mode – TCP Client Mode

In TCP Client Mode, device can establish a TCP connection with server by the method you have settled (Startup or any character). After the data has been transferred, device can disconnect automatically from the server by using the TCP alive check time or Idle time settings.




Figure 5-17 TCP Client Mode


The following table describes the labels in this screen.

| Label | Description |
|--------------------------|---|
| Encryption with SSL | Use SSL to encrypt data. |
| Destination Host | Set the IP address of host. |
| Port | Set the port number of data port. |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Connect on Startup | The TCP Client will build TCP connection once the connected serial device is started. |
| Connect on Any Character | The TCP Client will build TCP connection once the connected serial device starts to send data. |

Table 5-12TCP Client mode

Service Mode – UDP Mode

Compared to TCP communication, UDP is faster and more efficient. In UDP mode, you can Uni-cast or Multi-cast data from the serial device server to host computers, and the serial device can also receive data from one or multiple host



The screenshot displays a web-based configuration interface for the 'Service Mode' of a serial device. The interface is organized into several sections:

- Serial Settings:** Includes a tab for 'Service Mode' and a dropdown menu for 'Service Mode' set to 'UDP Mode'.
- UDP Mode:** A sub-section header.
- UDP Settings:** Contains a 'Listening Port' field with the value '4000' and an 'Auto Scan' button.
- MultiLink:** A section with a table for configuring multiple links. The table has three columns: 'Destination Host Begin', 'Destination Host End', and 'Sending Port'. There are four rows, each with an 'Auto Scan' button.
- Bottom Bar:** Contains three buttons: 'Refresh', 'Apply Only', and 'Apply and Save'.

| | Destination Host Begin | to | Destination Host End | Sending Port | Auto Scan |
|---|------------------------|----|----------------------|----------------------|--|
| 1 | <input type="text"/> | | <input type="text"/> | <input type="text"/> | <input type="button" value="Auto Scan"/> |
| 2 | <input type="text"/> | | <input type="text"/> | <input type="text"/> | <input type="button" value="Auto Scan"/> |
| 3 | <input type="text"/> | | <input type="text"/> | <input type="text"/> | <input type="button" value="Auto Scan"/> |
| 4 | <input type="text"/> | | <input type="text"/> | <input type="text"/> | <input type="button" value="Auto Scan"/> |



Technical Specifications

| ORing M2M Model | IMG-111 |
|---|---|
| Physical Ports | |
| 10/100 Base-T(X) Ports in RJ45 Auto MDI/MDIX | 1 |
| Sim card slot | 1 |
| Cellular Interface | |
| Cellular Standard | GSM / GPRS / EGPRS / EDGE / WCDMA / HSDPA / HSUPA |
| Band options | Dual band : HSUPA 1900 / 2100 MHz Quad band : GSM / GPRS / EDGE 850 / 900 / 1800 / 1900 MHz / WCDMA / HSDPA 850 / 900 / 1900 / 2100MHz |
| Antenna Connector | Reverse SMA |
| Antenna | GSM/DCS/UMT 3G antenna x1 |
| Serial Ports | |
| Connector | DB9 Male x 1 |
| Operation Mode | RS-232 |
| Serial Baud Rate | 110 bps to 115.2 Kbps |
| Data Bits | 5, 6, 7, 8 |
| Parity | odd, even, none, mark, space |
| Stop Bits | 1, 1.5, 2 |
| Serial signals | RS-232 : TxD, RxD, GND |
| LED Indicators | |
| Power indicator | Green On: Power is on and functioning Normally. |
| Status indicator | Green : System status indicator |
| Fault indicator | Amber on : WAN connection link down |
| WAN | Green on : 3.5G dial up Green blinking : 3.5G disconnect |
| Serial TX/RX LED | Red : Receiving data Green : Transmitting data |
| 10/100TX RJ45 port indicator | Green for port Link/Act. |
| Fault Contac | |
| Relay | Relay output to carry capacity of 1A at 24VDC |
| Power | |
| Power input | 12-48VDC power input on terminal block |
| Power consumption | 4.5 Watts |
| Physical Characteristic | |
| Enclosure | IP-30 |
| Dimension (W x D x H) | 41 (W) x 70 (D) x 95 (H) mm (1.61 x 2.76 x 3.74 inch) |
| Weight (g) | 360 g |
| Environmental | |
| Storage Temperature | -40 to 85°C (-40 to 185°F) |
| Operating Temperature | -10 to 60°C (14 to 140°F) |
| Operating Humidity | 5% to 95% Non-condensing |
| Regulatory Approvals | |



| | |
|-----------------|--|
| EMI | FCC Part 15, CISPR (EN55022) class A |
| EMS | EN61000-4-2 (ESD), EN61000-4-3 (RS), EN61000-4-4 (EFT), EN61000-4-5 (Surge), EN61000-4-6 (CS), EN61000-4-8, EN61000-4-11 |
| Shock | IEC60068-2-27 |
| Free Fall | IEC60068-2-32 |
| Vibration | IEC60068-2-6 |
| Safety | EN60950-1 |
| Warranty | 3 years |